

**\*CAMHOUSE**

<b>Body</b>	<b>Body Set</b>	<b>수량</b>
Camera Body with PL-Mount	ALEXA Body	1
SxS/ProRes Recording Module	SONY SxS 64GB / 32Gb Memory Cards	2 / 2
Center Camera Handle CCH-1	SONY SxS Reader set	1
Handle Extension Block HEB-2	Audio Cable(3 to 4 Pin Canon Cable) - 추가	1
Battery Adapter Back for V Mount BAB-V	HD Onboard Monitor 7" or 5.6"(TVLogic) / Sunshield	1
Electronic Viewfinder EVF-1	HD Monitor 17"(TVLogic) / Sunshield	1
Viewfinder Mounting Bracket VMB-1	Matte Box(MB-14 6.6"x6.6", LMB-5 4"X5.6")	1
Viewfinder Extension Bracket VEB-1	Follow Focus(FF-4)	1
Viewfinder Cable Short (1.2 ft) KC 150-S	Head	1
Viewfinder Cable Medium (2.1 ft) KC 151-S	Tripod(Long, Short, Hihat) Set	1
Leveling Block LB-1	IDX Batterys	8
Bridgeplate BP-8 (19mm)	Battery Charger	2
Bottom Baseplate	IDX EB2 or EB4	1
Support Rods 19mm Long / Short	ND(IR) 0.3, 0.6, 0.9, 1.2, PL, Clear Filters(6X6, 4X5.6)	1 set
Power Cable KC 20-S	Cart set / etc	1

\*CAMHOUSE

<b>ALEXA MODEL</b>	<b>ALEXA Plus 4:3</b>	<b>ALEXA</b>
<b>Super 35 sensor area</b>	4:3	16:9
<b>Number of sensor photo sites</b>	2880 x 2160	2880 x 1620
<b>Exposure latitude (stops)</b>	14	14
<b>Base sensitivity (EI)</b>	800	800
<b>Exposure Index (EI)</b>	160 - 3200	160 - 3200
<b>Frame rate 16:9 (fps)</b>	0.75 - 60(ProRes) 120(HD)	0.75 - 60(ProRes) 120(HD)
<b>Frame rate 4:3 (fps)</b>	0.75 - 48	-
<b>Sound level</b>	< 20 db (A)	< 20 db (A)
<b>Electronic shutter angle</b>	5 - 358	5 - 358
<b>Weight (Kg/lbs)</b>	8.4/18.5	7.7/16.9
<b>Electronic viewfinder</b>	○	○
<b>Optical viewfinder</b>	-	-
<b>In-camera recording to SxS PRO cards</b>	○	○
<b>In-camera ARRIRAW recording</b>	-	-
<b>In-camera ARRIRAW</b>	-	-
<b>In-camera ProRes 2K recording</b>	○	○
<b>In-camera ProRes HD recording</b>	○	○
<b>Lens Data System</b>	○	-
<b>HD-SDI video output connectors</b>	4	3
<b>24 V accessory power connectors (RS)</b>	3	2
<b>Integrated wireless camera and lens control</b>	○	-
<b>Tilt and roll sensors</b>	○	-
<b>Electronic horizon</b>	○	-